



Наборы шестигранников L-типа



№	Размер, мм
1125M	H3, H4, H5, H6, H8, H10, H12, H14



№	Размер, мм
1125M	H3, H4, H5, H6, H7, H8, H10, H12, H14, H17

Набор TORX L-типа



№	Размер, мм
1143R	T10, T15, T20, T25, T27, T30, T40

Наборы TORX TR L-типа



№	Размер, мм
1147R	T10H, T15H, T20H, T25H, T27H, T30H, T40H




№	Размер, мм
1147R	T10H, T15H, T20H, T25H, T27H, T30H, T40H, T45H, T50H



№	Размер
1127R	T10H, T15H, T20H, T25H, T27H, T30H, T40H, T45H, T50H



№	Размер
1163R	T10H, T15H, T20H, T25H, T30H, T40H



№	Размер
1163R	T10H, T15H, T20H, T25H, T27H, T30H, T40H, T45H, T50H

Раскладные TORX




Размер
T9, T10, T15, T20, T25, T27, T30, T40

Наборы SPLINE L-типа



№	Размер
1146MR	M5, M6, M8, M10, M12



№	Размер
1126M	M5, M6, M8, M10, M12